



Kawasaki Teryx Skid Plate Installation Instructions

1. Let skid sit in sun or inside house at room temperature for a couple hours. Cold weather can shrink plastic slightly but this is not an issue once installed.
2. Remove Stock Teryx Hardware/skids and set aside hardware to use on new skid
3. You have a couple options in mounting the new skids.
 - 1) remove stock metal engine inspection cover underneath Teryx, or
 - 2) using UHMW skid as template cut out hole in inspection cover **(A below)** to allow access to oil filter. Cut hole substantially larger than skid hole so as not to cut yourself when removing/installing oil filter
5. Fasten all main skid bolts and washers, but do not tighten all the way so that you are able to move skid slightly to center all bolt holes.
6. Fasten all front and rear skid bolts and washers, but do not tighten all the way so that you are able to move skid slightly to center all bolt holes.
 - . Once skids are in desired location tighten all bolts
9. You will be required to drill 2 - 3/16 pilot holes in the 2 rear most main skid mounting locations. Use the supplied self tapping bolts and washers to attach skid in these locations

Feel free to call or e-mail us with any questions

916-207-8335 - info@factoryutv.net

