



RZR 170 Swingarm Installation Instructions

***** THESE ARE TEMPORARY INSTRUCTIONS, Pictures coming soon*****

1. Jack up rear of RZR and support ahead of rear axle (A)



2. Remove rear tires and rims
3. Remove disc brake caliper, when sliding off it's a good idea to slide something the same width of the disc between the brake shoes as you pull the caliper off.
4. Remove chain guard and chain
5. Remove Axle bearing bolts
6. Remove lower shock bolts and drop swingarm, then remove axle
7. Remove swingarm bolts and swingarm

8. Remove chain tensioner and install on FUTV swingarm
9. Install new FUTV swingarm with bolts through heim ends.
10. Install lower shock bolts
11. Install axle and lightly snug axle bearing bolts
12. Install brake caliper
13. Install supplied chain links on chain and install chain
14. Adjust chain and tighten axle bolts
15. reinstall tires and wheels
16. Test drive and re-adjust chain if necessary

Please give us a call if you have any questions? 916-207-8335